

# Site Work Apparel Guidelines

Information from 24590-WTP-GPP-RAWS-IS-0010

Wearing long sleeve shirts with high-visibility vests/garments provides visibility to others working in ever-changing work areas, including HLW Facility areas that are ramping up construction activities.

## ACTIVE CONSTRUCTION ZONES

When in ACZs, all personnel, including workers and visitors, must wear both of the following:

1. **WEAR** a long sleeve shirt or jacket that covers the wrist.

- There is no restriction on the shirt other than it covers the wrist.

2. **WEAR** orange high-visibility outer garment (e.g., shirt, vest, or jacket) in accordance with

ANSI/ISEA 107 Type "R" Class 2 unless a different high visibility color is specified by activity.

- **WHEN** activity hazard controls determine they are required (e.g., hot work, electrical switching),
- **THEN USE** flame-resistant high-visibility garment (e.g., welding jacket, apron, vest, or shirt)
- Note it is acceptable to wear the Project-provided high-visibility orange shirts without a vest (as pictured, left).



## NOT ACTIVE CONSTRUCTION ZONES

- Appropriate shirts must be worn that cover the entire upper torso and have a minimum sleeve length of 4 inches from the shoulder.
- Full-length pants that extend to the ankle, made of sturdy material, without holes, tears, rips, or cuts must be worn.
- Minimum foot protection includes substantial hard-soled boots or shoes with tops made of durable, sturdy material (i.e., leather, combination leather and nylon mesh, man-made materials, etc.).
- Tennis/athletic shoes that meet ASTM F2413 standards
- Open toed shoes, sandals, moccasins, high- heels, boat shoes, mules, etc., are not acceptable.



*Managers and supervisors are responsible for ensuring that employees exercise good judgment and have the right to ask the employee to return home to change into appropriate attire.*